


## TEST POINTS

### R-T-FP

ORFS IN-LINE TEST POINT ADAPTOR  
ORFS MALE X FEMALE W. BSPP PORT ON HEX



Part Number	ORFS Male Thread (A)	ORFS Female Thread (B)	BSPP Female Thread (C)	L1 - mm	Hex A/F (CH1)	Hex A/F (CH2)
R-T-FP-090902	9/16-18	9/16-18	1/8-28	39.4	27	19
R-T-FP-111102	11/16-16	11/16-16	1/8-28	41.7	27	22
R-T-FP-131302	13/16-16	13/16-16	1/8-28	46	27	24
R-T-FP-161602	1-14	1-14	1/8-28	48.5	31.8	30
R-T-FP-191902	1.3/16-12	1.3/16-12	1/8-28	52	31.8	36
R-T-FP-232302	1.7/16-12	1.7/16-12	1/8-28	55	31.8	41